

## SIGA Fentrim Base Joint Assembly

Siga Fentrim is a rugged tape for use in many applications. Taping the base joint, sheathing across sill plate to foundation is one of the easiest and most effective measures to air-seal and weather seal a building. This will also minimize insects from entering and protect the bottom edge of the sheathing from splash-back of water and dirt.

Suggested sequencing (may vary based on project specifics):

- 1) Clean surfaces of dirt.
- 2) Snap a line 2" onto the concrete foundation.
- 3) Apply Fentrim (4" or 6") to line on concrete. Use the tape release backing to your advantage!
- 4) Work tape up and over the sheathing. Be sure to tuck the tape into the corner and not leave an air space.
- 5) Apply even pressure to tape with squeegee or roller to remove any air bubbles and complete adhesion.
- 6) Apply Majvest WRB over sheathing and lap over Fentrim at base.
- 7) Tape Majvest to Fentrim with Wigluv-60 or Fentrim 4".
- 8) Be sure to install siding low enough to cover the Fentrim tape.

Links:

Fentrim 4" - <https://sigatapes.com/product/fentrim-f/>

Fentrim 6" - <https://sigatapes.com/product/fentrim-f-6/>

Wigluv-60 - <https://sigatapes.com/product/wigluv-60/>

Majvest - <https://sigatapes.com/product/majvest-0-5/>

Majvest-SA - <https://sigatapes.com/product/siga-majvest-sa-5ft/>

